

AUTOMATIC COOKTOP FIRE SUPPRESSION

STOVETOP FIRESTOP MICROHOOD®



StoveTop FireStop Microhood offers residences with over-the-stove microwaves reliable, fully automatic fire protection. It keeps you from fumbling with a fire extinguisher or getting dangerously close to an out-of-control fire.

Available in black or white to match your appliances, StoveTop FireStop Microhood dispenses fire-suppressing powder to stovetops with 15-27 inches between the bottom of microwave and cooking surface.

StoveTop FireStop is America's leading line of automatic stovetop fire suppressors, with a 40-year track record.



HOW DOES THE MICROHOOD WORK?



- » A pair is needed per cooktop.
- » When flames from a grease fire on the front burner touch the bottom of the device, the front ramp opens.
- » The front ramp is designed to deliver fire-suppressing powder directly to the front burner, a rear canister will deliver powder to the back burner if needed.
- » Delivers fire-suppressing powder automatically via the ramp to both front and back burners when flame activated

HOW DO I INSTALL THE MICROHOOD?

StoveTop FireStop Microhood attaches to the wall below microwave ovens or kitchen cabinetry. To install:

1. Determine wall attachment method based upon type of backsplash (found in instructions).
2. Align wall bracket with the center line of the burner.
3. Attach bracket securely to the wall, then slide housing onto bracket.
4. Repeat steps 1-3 for the second unit on the other side of the stove.

Use your smartphone's barcode reader to see StoveTop FireStop Microhood in action.



STOVETOP
FIRESTOP